



NOTES:

1. ALL BUS STOPS MUST PROVIDE A 5' WIDE BY 8' DEEP ADA CONCRETE PAD (LESS THAN 2% SLOPE IN ALL DIRECTIONS).
2. IF BACK OF CURB IS LESS THAN 3.5' FROM SIDEWALK, FILL AREA WITH 6" CONCRETE.
3. DOWEL CURB INTO 8" CONCRETE USING #4 REBAR SPACED 30" ON CENTER.